





























9.1 Service schedule

Any further work that results from the service work must be ordered separately and invoiced separately.

Different service intervals may apply in your country, depending on the local operating conditions.

If the vehicle is used in particularly harsh conditions such as heavy rain, mud, sand, snow, extreme temperatures, frequent full load etc., shorter service intervals than those in the table may be necessary.

Individual service intervals and scopes may change in the course of technical developments. The most up-to-date service schedule is available for authorized dealers for the electronic proof of service. Your authorized dealer will be happy to advise you.

	Every 24 months				
	Every 90 operating hours				
	Every 45 operating hours				
	Every 15 operating hours				
	After one operating hour				
Read out the fault memory using the diagnostics tool. 	○	●	●	●	●
Program the gear position sensor. 		●	●	●	
Check that the electrical equipment is functioning properly.	○	●	●	●	
Check and charge the 12 V battery. 		●	●	●	●
Check that the brake pads of the front brake are secured.  (p. 80)	○	●	●	●	●
Check that the brake pads of the rear brake are secured.  (p. 85)	○	●	●	●	●
Check the brake discs.  (p. 78)	○	●	●	●	●
Check the brake lines for damage and tightness.	○	●	●	●	●
Check the brake fluid level for the front brake.  (p. 79)	○	●	●		
Change the brake fluid for the front brake. 				●	●
Check the brake fluid level for the rear brake.  (p. 84)	○	●	●		
Change the brake fluid for the rear brake. 				●	●
Check/correct the fluid level of the hydraulic clutch.  (p. 75)			●		
Change the hydraulic clutch fluid.   (p. 76)				●	●
Check the free travel on the hand brake lever.	○	●	●	●	●
Check the free travel of the brake pedal.  (p. 83)	○	●	●	●	●
Check the idle speed.	○	●	●	●	●
Change the engine oil and the oil filter, clean the oil screens.   (p. 114)	○	●	●	●	●
Check all hoses (e.g. fuel, cooling, bleeder, drainage, etc.) and boots for cracking, leaks, and correct routing. 	○	●	●	●	●
Check the cables for damage and that there are no kinks in the routing. 		●	●	●	●
Check that the clutch cables are undamaged, routed without kinks, and set correctly.		●	●	●	●
Check the frame.   (p. 73)		●	●	●	
Check the swingarm.   (p. 73)		●	●	●	
Check the swingarm bearing for play. 			●	●	
Check the heim joint on the shock absorber for play. 			●	●	
Check the shock absorber linkage. 		●	●	●	
Check the tire condition.  (p. 93)		●	●	●	●
Check the tire pressure.  (p. 93)		●	●	●	●
Check the wheel bearing for play. 		●	●	●	

9 Service schedule

		Every 24 months			
		Every 90 operating hours			
		Every 45 operating hours			
		Every 15 operating hours			
		After one operating hour			
Check the hubs.			•	•	•
Check the rim run-out.	○		•	•	•
Check the spoke tension. (p. 94)	○		•	•	•
Check the chain, rear sprocket, engine sprocket, and chain guide. (p. 70)	○		•	•	•
Check the chain tension. (p. 68)	○		•	•	•
Grease all moving parts (e.g., hand lever, chain, etc.) and check for smooth operation.	○		•	•	•
Change the spark plug and spark plug connector.				•	•
Check the valve clearance.	○			•	•
Change the fuel filter.					•
Check the clutch.			•	•	•
Clean the air filter and air filter box. (p. 61)			•	•	•
Change the glass fiber filling of the muffler. (p. 63)				•	•
Carry out fork service.				•	•
Service the shock absorber.				•	•
Check all screws, nuts, and hose clamps for a tight fit.	○		•	•	•
Change the fuel screen. (p. 113)	○		•	•	•
Check the fuel pressure.	○			•	•
Check the frost protection and coolant level. (p. 102)				•	•
Check the coolant level. (p. 103)	○		•		
Change the coolant. (p. 105)					•
Check the steering head bearing play. (p. 50)	○		•		
Lubricate the steering head bearing. (p. 51)				•	•
Perform minor engine service including removing and installing the engine. (Change the piston, check/measure the cylinder. Check the cylinder head. Check the camshaft and valve train components. Check the timing assembly. Change the radial shaft seal rings of the water pump. Change the crankshaft seal ring. Change the intake flange. Change inlet sleeve. Change the preload ring screws of the clutch.)				•	•
Perform major engine service, engine is removed. (Change valves, valve springs, valve spring seats, and valve spring retainer. Change the connecting rod, conrod bearing and crank pin. Check the transmission and shift mechanism. Check the oil pressure control valve. Change the suction pump. Check the force pump and lubrication system. Change the timing chain. Change all engine bearings and all gaskets. Change the freewheel.)					•
Final check: check vehicle for operating safety.	○		•	•	•
Take a test ride.	○		•	•	•
Read out the fault memory after the test ride using the diagnostics tool.	○		•	•	•
Enter electronic proof of service.	○		•	•	•

- One-time interval
- Periodic interval